



# Asus Vivobook Max X541SA-PD0703X Track Pad Replacement

This guide will provide instructions on how to access the interior parts of the Asus Vivobook Max X541SA-PD0703X and replace the track pad.

Written By: Hetvi Mehta



## INTRODUCTION

This guide will show you how to remove and replace the track pad of your Asus Vivobook Max X541SA-PD0703X. There are no additional parts that you need to replace in order to access the track pad.



### TOOLS:

- [iFixit Opening Tools](#) (1)
- [Phillips #0 Screwdriver](#) (1)
- [Tweezers](#) (1)



### PARTS:

- [Track Pad](#) (1)

## Step 1 — Keyboard



- Flip the laptop upside down so that the back of the laptop faces you.


## Step 2



- Remove the following ten Phillips #0 screws from the bottom of the laptop:
  - Six 13mm screws.
  - Four 11mm screws.






## Step 3




- Using a plastic opening tool, pry up the palm rest from the bottom half of the laptop.
- ⓘ Ribbon cables connect the two half so don't remove completely.

## Step 4




- Use a spudger to flip up the retaining flap on the keyboard ribbon cable [ZIF](#) sockets.
- Pull the ribbon cables out of their sockets.

## Step 5



- Take the keyboard half of the laptop and place it in front of you so that they keys are facing down.


## Step 6



- Remove the three 3mm Phillips #0 screws from the touchpad.




## Step 7



- Use a spudger to flip up the retaining flap on the touch pad ribbon cable [ZIF](#) socket.
- Pull the ribbon out of the socket.

## Step 8



- Remove the touchpad.

To reassemble your device, follow these instructions in reverse order.