




# Acer Aspire 5253 RAM Replacement

Make sure to remove the battery first to avoid...

Written By: Cynthia Barajas



# INTRODUCTION

Make sure to remove the battery first to avoid any incidents.

---

## TOOLS:

[Phillips #00 Screwdriver](#) (1)

[iFixit Opening Tool](#) (1)

---

## Step 1 — Battery



- Turn the laptop over.

## Step 2



- "Unlock" your battery by moving the switch as shown so that an unlocked lock on a red background is shown.

## Step 3



- Next move the other switch, while the unlocked symbol is still showing. The battery should pop up, and no longer be flush with the bottom of the laptop.

## Step 4



- Now remove the battery by lifting it out of the laptop by the side closest to the switches.

## Step 5



- You have successfully removed the battery. Congratulations!

## Step 6 — Back Cover Panel



- Now, locate the two screws that hold the back cover panel onto the laptop.

## Step 7



- Unscrew both of the screws that are holding the back panel in place with the Philips #00 head.
- ⓘ The screws are 3/8" in length and have a 1/4" head.

## Step 8



- Once both screws have been removed use a plastic opening tool to lift the panel up. Starting with the indented notch , and moving left and right from there.

## Step 9



- After the panel has been loosened by the plastic opening tool, take your finger, place it in the gap, and remove the panel from the laptop.

## Step 10 — RAM



- Now, locate the RAM.

## Step 11



- Locate the two metal pieces on both sides of the RAM that are holding it in place.

## Step 12



- Pull the tabs apart to remove the RAM.
- ❗ The RAM will pop up once they are pried open.

## Step 13



- Carefully slide the RAM out of the compartment.

To reassemble your device, follow these instructions in reverse order.