

Xbox One Wireless Controller Bottom Motherboard Replacement

This guide will show you how to remove the...

Written By: Liam Gow



INTRODUCTION

This guide will show you how to remove the motherboards in order to access the buttons and triggers.



TOOLS:

Tweezers (1)

T6 Torx Screwdriver (1)

TR8 Torx Security Screwdriver (1)

Soldering Iron 60w Hakko 503F (1)

Spudger (1)



PARTS:

Xbox One Controller Motherboard (1)

Step 1 — Battery Pack



- Remove the battery pack cover.
- Remove batteries.

Step 2 — Side Handles





- i We recommend using a nylon spudger for this step. A metal spudger is shown.
- Grip the controller firmly to remove the side handles, wedging a spudger into the seam between the front and handle plates.
- Pry the side plate away from the front plate by moving the spudger back and forth. You will
 need to do this all the way around the side plate's seam.

Step 3 — Screws





- i There is a hidden screw located in the middle of the controller behind the label.
- Use a screwdriver and punch a hole directly in the center of the label.
 - i You may also lift the label if you do not want to puncture it.
- Remove the five 10mm screws located on the back of the controller using the TR8 Security Torx Screwdriver.

Step 4 — Backplate




Remove the backplate.


Step 5 — Faceplate



Remove the faceplate.

Step 6 — Top Motherboard






- You may let the rumble motors hang freely out of their sockets.
- De-solder the soldered joints while holding the red and black wires down on the top motherboard.
- De-solder the black and gray wires that are attached to the top motherboard.
- Remove the rumble motors and set them aside.
- A Be careful while using the soldering iron not to damage other components or hurt yourself.
- i For information on how to solder, click here.



 Unscrew the two 7mm T6 screws located near the rumble motor sockets.




- Firmly grip sides of motherboard near the middle.
- Lift upwards while slightly wiggling the motherboard forward and backward.
- i Lifting the motherboard will require some force.


Step 9 — Trigger Rumble Motors



 Remove the yellow tape holding the wires in place on the front of the controller.


Step 10








• Unscrew the two 7mm T6 Hex screws located on underside the triggers.



• Remove the trigger covers.




- i Desolder the wires from the motherboard.
 - Remove the rumble motors from its socket and pull the wire with it.

Step 13 — Bottom Motherboard





Remove the six T6 Torx screws located on the bottom motherboard.






- Remove the bumpers by prying them off of the pegs that secure them, using a spudger. They are located on the front and back of the controller.
- A standard nylon spudger is recommended for this step. Using a metal spudger near the motherboard as shown risks damaging your device.





- Lift the piece surrounding the Home button off of its pegs.
- Pry it off of the other side, using a spudger on the pins.
- A standard nylon spudger is recommended for this step. Using a metal spudger near the motherboard as shown risks damaging your device.
- (i) Removing this piece may require a lot of force.



• Remove the bottom motherboard.

To reassemble your device, follow these instructions in reverse order.