

Samsung Galaxy S II Teardown

The innards of the Samsung Galaxy S II.

Written By: Ion



INTRODUCTION

This is an unofficial teardown to iFixit of the great Samsung Galaxy S II, enjoy! ;)



TOOLS:

- Phillips #00 Screwdriver (1)
- iFixit Opening Tools (1)

Step 1 — Samsung Galaxy S II Teardown







The 4.3-inch super Amoled Plus display is simply gorgeous!





- Look at how slim the phone is! Only 8.49mm thin!
- Back cover is flexible but don't worry it will not break. It also has a nice texture to it.



- Look at how compact everything is inside!
- Remove the seven visible screws.
- Then unclip the back panel starting on the left next to the audio jack. Go slowly.

Step 4










Removing the back panel gives you an impressive and sophisticated view of the internals.






- Removing the motherboard is as simple as it looks!
- Unclip the 5 ribbon connectors and the antenna cable.
- Then remove the 2 small black screws.
- Don't forget to unglue the volume flex and power flex, they are attached to the motherboard.
 Otherwise the motherboard won't come out easily like it should.







- The board with removed EMI shields.
- The front.
- ..and the back.
- The front panel without the logic board.
- The front facing camera part, the cinch-vibrator-1.mic part and the usb connection-2.mic-antenna board.






- The camera connector is at the upper left corner in the second picture.
- The power and volume buttons are soldered to the logic board.
- Niew the picture in HQ if you want to be impressed!




- This EMI shield is nearly a heat sink.
- Should be useful with a 1.2GHz dual core under it!










- The (tiny) 8MP camera.
- It's smaller than an iPhone 4 camera.







- The front-facing camera and the light sensor are a single part.
- The front-facing camera is 2MP, which is better than the iPhone 4's VGA camera.





The vibrator, first mic (did you know there are two?), cinch plug and the earspeaker.





- The USB-connection and 2 x mic board.
- It's stuck with glue to the front panel.
- The (only) antenna cable and a metal shield holding the light sensor in place.





- This is it.
- It still works after reassembly!

To reassemble your device, follow these instructions in reverse order.