![iFIXIT]

HUAWEI HONOR 5X Fingerprint Scanner Replacement

How to replace the finger print scanner in the HUAWEI HONOR 5X.

Written By: Klara Asllani

INTRODUCTION

If the device does not recognize fingers correctly, replacing the fingerprint scanner may solve this issue.

🔧 TOOLS:

- Phillips #000 Screwdriver (1)
- T3 Torx Screwdriver (1)
- iOpener (1)
- iFixit Opening Tools (1)
- SIM Card Eject Tool (1)

This document was generated on 2020-11-28 06:37:44 AM (MST).

Step 1 — HUAWEI HONOR 5X Disassembly

- Turn off your cell phone before disassembling.

Step 2

- Remove the two 1.17mm Torx T3 screws from the bottom of the phone.

This document was generated on 2020-11-28 06:37:44 AM (MST).

Step 3

- Use the Sim card ejection tool to remove both the sim card trays.

|

Step 4

- To prepare the iOpener insert it in the microwave for 30 seconds and apply it on the side edges of the phone so that the glue underneath will soften.

Step 5

- Pry off the back with a plastic opening tool.

Step 6 — Motherboard

- Remove the five 1.5mm Phillips #000 screws from the motherboard.

Step 7

- Use a plastic opening tool to pry up and disconnect the display cable from the motherboard.
- Use tweezers to disconnect the white coax cable.
- Use tweezers to disconnect the power and volume cable.

This document was generated on 2020-11-28 06:37:44 AM (MST).

Step 8

- Remove the motherboard.

Step 9 — Fingerprint Scanner

- Pull the fingerprint scanner out of its housing.

Step 10

- This is what the mother board should look like when the fingerprint scanner is pulled out.

- To fix the fingerprint scanner simply add in a new one and attach the metal component to its coordinating place.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-28 06:37:44 AM (MST).