



Dell Inspiron N4110 Battery Replacement

Does your battery not stay charged, or charge at...

Written By: Julia Dunn



INTRODUCTION

Does your battery not stay charged, or charge at all? It's probably time for a replacement, and this will take only a few seconds to complete. You will need to purchase a new battery.



PARTS:

[Dell DL-I13R Battery](#) (1)

Step 1 — Battery



⚠ Make sure the laptop is off and unplugged before starting this step.

- Locate the battery on the underside of the laptop.
- Push the two battery clips following the direction of the arrows.

Step 2



- Push upward from the base of the battery.

Step 3



- Pull battery away from computer until it is fully removed.

To reassemble your device, follow these instructions in reverse order.