



HP Officejet Pro 8600 Plus Control Panel Replacement

How to replace the HP Officejet Pro 8600 Plus control panel.

Written By: Mackinnon Buck



INTRODUCTION

The control panel on the HP Officejet Pro 8600 plus may have touchscreen issues or display problems. This guide describes how to replace the control panel.

TOOLS:

- [iFixit Opening Tools](#) (1)
 - [T10 Torx Screwdriver](#) (1)
-

Step 1 — Control Panel



- Lift the scanner lid to a resting position.

Step 2



- Wedge the plastic opening tool into each of the three plugs to pry them from the control panel hinge located above the control panel screen.

Step 3



- Remove the three 10mm-T10 Torx screws.

Step 4



- Disconnect the control panel from the hinge by gently lifting upward, then outward towards you.

Step 5



- Detach the control panel from the black plastic latch by gently lifting upward, then outward towards you.
- ⓘ Pull up on the left side when sliding up so the panel does not get stuck at the end of the track.

Step 6



- Turn over the control panel, making the screen face downwards.
- Place two fingers on the rectangular, plastic wire cover and squeeze inward. Slide the cover downward, away from the cables, until the cover is fully removed.

Step 7



- Disconnect the two ribbon cables from the panel by pulling them upward out of their ports.
- ⓘ This does not break the cables. They can easily be reconnected by plugging them into their ports again.

To reassemble your device, follow these instructions in reverse order.