



Fisher and Paykel DEGX1 No Heat Fix

This guide will show how to repair your Fisher...

Written By: Dan Dunham

Fisher and Paykel model DEGX1 No heat fix



INTRODUCTION

This guide will show how to repair your Fisher and Paykel DEGX1 dryer if it isn't heating up.



TOOLS:

- [Phillips #2 Screwdriver](#) (1)
 - [Slip Joint Pliers](#) (1)
-

Step 1 — Fisher and Paykel DEGX1 No Heat Fix

- take a look at this short video

Fisher and Paykel model DEGX1 No heat fix



To reassemble your device, follow these instructions in reverse order.