



# Alcatel Pop 4 Plus Headphone Jack Replacement

The correct way to replace the Headphone Jack on an Alcatel Pop 4 Plus.

Written By: Garrett Marler



# INTRODUCTION

## Caution: Lead Contaminate

Please use extreme caution when handling a Soldering tool. Tool will produce extreme heats. For more information on soldering, please read the [How to Solder and Desolder Connections guide](#).




If your phone is not playing audio correctly or you notice that your headphones slide in and out without staying in, you may need to replace your headphone jack.



## TOOLS:


- [Phillips #000 Screwdriver](#) (1)
  - [Curved Needle Nose Pliers](#) (1)
  - [Spudger](#) (1)
  - [Soldering Iron](#) (1)
  - [Solder](#) (1)
-

## Step 1 — Headphone Jack




- Begin by removing the back of the phone. Press your nail or a thin object in the bottom right-hand corner of the phone and gently press to release the back of the phone from the front.

## Step 2




- Remove seventeen 1.2mm screws from the phone's mid-frame using the Phillips #000 screwdriver.

## Step 3



- Once the screws have been taken out, remove the mid-frame protecting the phone's electronics by using a fingernail or tool to pry it off.



## Step 4



- Disconnect the battery from the motherboard and remove it.





## Step 5





- Unhook the USB ribbon from the motherboard.

## Step 6





- Disconnect the phone's ribbon cable from the mother board.

## Step 7



- Disconnect the ribbon cable that binds the two motherboards together.


## Step 8



- Remove the phone's rear camera from the motherboard.






## Step 9




- Insert a flat tool at the edge of the phone and gently lift to remove the motherboard.

## Step 10



- Locate the phone's headphone jack on the motherboard.

## Step 11



- Apply heat to the four connections using a soldering tool to remove the old headphone jack.
- ⓘ For more information on soldering, please visit the [How to Solder and Desolder Connections guide](#).

To reassemble your device, follow these instructions in reverse order.