



ZD-N Plus Wireless Controller Back Panel Replacement

A guide to show how to remove and replace the back panel on the ZD-N Plus Wireless Controller.

Written By: Stacie Schmidt



INTRODUCTION

This Guide is a prerequisite for any repairs done on the inside of the ZD-N Plus Wireless Controller. This is going to be the first step to a repair involving the ZD-N Plus Wireless Controller.

TOOLS:

- [JIS #00 Screwdriver](#) (1)
-

Step 1 — Back Panel



- Remove the seven 12mm JIS #00 screws that hold the back panel in place.

Step 2



- Lift up on the back panel of the ZD-N Plus to remove it from the rest of the controller.

To reassemble your device, follow these instructions in reverse order.