



# 2014 Subaru Forester Headlight Replacement

Learn how to quickly change the headlights in your 2014 Subaru Forester without any knowledge or experience required.

Written By: Andrew Burney



## INTRODUCTION

Replacing headlight bulbs can be tricky, and since it is all done by hand (with no tools) it is easy to not understand what to pull/rotate. This guide will explain the exact steps needed to successfully remove and replace the headlight bulbs on a 2014 Subaru Forester entirely by yourself.



### PARTS:

- [Headlight Bulb](#) (1)

H11

*Low-Beam*

---

## Step 1 — Low-Beam Headlights



- Make sure you have the correct replacement part. For the specified model, the **H11 Headlight Bulb** is the stock-standard replacement bulb (found at any automotive store).

## Step 2



- Open the hood of your car by locating and pulling the hood release found on the driver side dash just below (and to the left) of the steering wheel. Then move to the front grill of your car and pull the latch located under the Subaru symbol.



### Step 3



- Move to the side that harbors the burnt-out headlight. Locate the headlight assembly which is positioned right behind the headlight itself.

### Step 4



- Reach inside the headlight assembly to find the base of the bulb. Push in the release tab ( **which is the indentation found on the base below the blue tag**), then move the power plug downward from the old bulb with above-moderate force.

## Step 5



- Grab the base of the old bulb and rotate it a quarter length **counterclockwise** and then you will be able to pull it straight out.

To reassemble your device, follow these instructions in reverse order.