



DJI Mavic 2 Pro Battery Replacement

This guide will illustrate how to change your "...

Written By: Thomas Forcier



INTRODUCTION

This guide will illustrate how to change your "DJI Mavic 2 Pro" battery. If the device is experiencing power-related issues, it may be caused by problems with the battery. Please ensure your device is powered off and disconnected from any external power source before beginning. The process is simple and should not take much time. There will be no tools needed.



PARTS:

- [DJI Spark Intelligent Flight Battery](#) (1)
-

Step 1 — Battery



- Press the buttons on the sides of the drone and pull the battery upwards from the drone to remove it.
- Set aside and charge dead battery.

Step 2



- ★ Press the buttons on the sides of the drone and push the battery downwards into the drone.
- Ensure the battery is secured in place.

Step 3



- After making sure the battery is well placed, turn on the device.

If all directions are followed, you have successfully replaced your DJI Mavic 2 Pro battery.