

Shark ION Robot S87 Filter Replacement

An easy guide to replace the filter of your Shark ION Robot S87.

Written By: Tommy Chang



INTRODUCTION

Is your Shark ION Robot S87 sound alarm blinking or is there no suction anymore? The primary reason for these occurrences is dirty filters. Dirty filters are caused by debris and hair being sucked into the vacuum. To avoid this, change your filter periodically because they get dirty, and may even crack from various items. If you are experiencing this issue, here is an easy guide to fix it.



PARTS:

Shark ION S87 Filter (1)

Step 1 — Filter





- Flip the Shark ION Robot so that the underside is facing up.
- Hold the button on the bottom of the vacuum, and slide the tray away from the device.

Step 2







Detach the orange filter by holding the grip out from the trash tray.

To reassemble your device, follow these instructions in reverse order.