

## Dreamer Autoshade Bottom Bar Pouch Replacement

Fix a detached bottom bar for the Dreamer Autoshade

Written By: David





• Super glue (cyanoacrylate) (1)

## Step 1 — Prepare Bottom Bar



 Place the shade and bottom bar on a flat surface. To require less space, roll the shade so only the bottom bar is showing.

## Step 2 — Add Glue







- Add a drop of super glue directly to the double-stick tape.
- Hold the shade material on the applied glue. The glue should dry in 10-20 seconds.
- Repeat this process in any area on the bottom bar that comes unstuck.

To reassemble your device, follow these instructions in reverse order.