



# DualShock 4 CHU-ZCT2U Rear Panel Replacement

Follow this guide to replace the rear panel on...

Written By: Sam Omiotek



## INTRODUCTION

Follow this guide to replace the rear panel on a Sony Dualshock 4 CHU-ZCT2U PlayStation controller.

### TOOLS:

- [iFixit Opening Tool](#) (1)
- [Phillips #00 Screwdriver](#) (1)

### PARTS:

- [DualShock 4 Controller Rear Panel \(CUH-ZCT2U\)](#) (1)

## Step 1 — Remove the rear panel screws



- Use a Phillips screwdriver to remove the four 6.4 mm-long screws from the rear panel.

## Step 2 — Separate the rear panel



- ❗ Four fragile plastic clips hold the panels together. You can see their locations more clearly in [this guide](#).
- ❗ The clips help hold the seams together. If you break these clips, the controller will still work.
- Insert an opening tool into the crease where the front and rear panel meet, starting from the outside edge of either handle.
- Gently pry the rear panel off of the front panel until they become partially separated.

## Step 3 — Release the plastic clips



- Use the opening tool to separate the panels by releasing the plastic clips around the perimeter of the controller.

## Step 4 — Remove the rear panel



- Lift the rear panel directly away from the controller.

**⚠ Do not completely remove the rear panel. It is still attached to the controller by a ribbon cable.**

## Step 5



- Use your fingers to gently pull the ribbon cable straight out of its connector on the motherboard.
  - ⓘ Since this cable's pull tab is too small to grab with fingers or tweezers, grab the cable itself. Otherwise utilize pull tabs whenever possible.
- ☑ During reassembly, grab the ribbon cable by the blue tab and gently press the cable straight into the connector. Push the blue tab rather than the ribbon cable itself.

**To reassemble your device, follow the above steps in reverse order.**

Repair didn't go as planned? Check out our [Answers community](#) for troubleshooting help.