

Epson EX90 Lamp Replacement

How to access and replace the lamp in an Epson EX90.

Written By: Antonio Morais



INTRODUCTION

This guide will show you how to replace the lamp in an Epson EX90 projector. If your projector is overheating, make sure your cooling fan is clean and functional.

Step 1 — Lamp



- Turn off the projector and unplug the power cable.
- Allow the projector to cool down for at least one hour (or until the lamp is cool).

Step 2



- Loosen the screw holding the lamp cover on top of the projector.
- Slide the cover out of the projector.

Step 3





- Loosen the two captive screws holding the lamp in place.
- Use your hands to pull the lamp straight up and out of the projector.

To reassemble your device, follow these instructions in reverse order.