

How to clean the Nintendo 64 cartridge slot

Written By: tonymag28



INTRODUCTION

Cleaning the cartridge slot will fix most of the problems with the Nintendo 64.



TOOLS:

- Q-Tips (1)
- Compressed Air (1)

Step 1 — How to clean the Nintendo 64 cartridge slot



 Open the slot with your finger. Blow along the length of the cartridge slot with the air duster.

Step 2



Moist a q-tip with rubbing alcohol.
Rub it along the length of the cartridge slot.

If cleaning the cartridge slot worked, you should be able to insert a game and play normally. If the game still does not boot normally, check to make sure the pins are not damaged, and that the cartridge does not need cleaning.