

INTRODUCTION

Replacing the battery in your Fairphone is easy and requires no tools.



TOOLS:

- [Fingers](#) (1)



PARTS:

- [Fairphone Battery](#) (1)

Step 1 — Back Cover



i There is a small indentation in the side of the phone near the bottom of the back cover.

- With the indentation as leverage, use your fingernail to pry the bottom portion of the back cover from the phone.

Step 2



- Slide the back cover down and remove it from the phone.

Step 3 — Battery



- i There is a small indentation in the back of the phone just below the battery.
 - Use a fingernail in this indentation to push the battery toward the top of the phone
 - Pull the battery out away from the phone.

Step 4



- Remove the battery from your Fairphone.

To reassemble your device, follow these instructions in reverse order.