


Samsung Juke Motherboard Replacement

This guide is a step-by-step guide on how to...

Written By: Renee Kuzniar



INTRODUCTION

This guide is a step-by-step guide on how to replace a Samsung Juke motherboard.



TOOLS:

- Phillips #00 Screwdriver (1)
- iFixit Opening Tool (1)



PARTS:

Samsung Juke SCH-u470 logic board (1)

Step 1 — Battery



 Press and hold down the button on the bottom side of the phone with your finger.


Step 2





While holding the button down, remove the back cover of the phone.

Step 3 — Camera/Speaker



 Remove the four screws from the back of the phone using a Phillips #00 screwdriver.

Step 4



 Remove the two 7.3 mm screws from the camera and the speaker at the bottom back plate of the phone using a Phillips #00 screwdriver.

Step 5








 Locate the USB port (where the charger can be plugged in). Using the iFixit opening tool, open the phone cover.

⚠ Failure to open USB port cover at this stage may result in damaging the device.


Step 6



 Remove the 5.5 mm screws from both sides of the camera/speaker with a Phillips #00 screwdriver.

Step 7







Use the iFixit opening tool to remove the camera/speaker from the motherboard.

Practice caution to prevent damage to the attaching ribbon.


Step 8






• Use the iFixit opening tool to gently pry the camera/speaker off.


Step 9 — **Motherboard**






Use the iFixit opening tool to remove the yellow tab on the motherboard.

Step 10







• Use the iFixit opening tool to remove the other orange tab to free the motherboard.

Step 11







- To completely remove the motherboard, use the iFixit opening tool to leverage it up, then use your fingers to pull it out.
- On not be alarmed if the volume and hold buttons are removed from the motherboard.

To reassemble your device, follow these instructions in reverse order.