



HTC One X SIM Card Tray Replacement

Replace or fix loose Sim Card Tray so that your device can detect your Sim.

Written By: Blain Abebe



INTRODUCTION

Before proceeding to fix the Sim Card tray, make sure the issue regarding the sim card detection isn't due to a faulty sim card.

TOOLS:

- [Safety Pin](#) (1)
-

Step 1 — SIM Card Tray



- Insert a safety pin or other small object in the small opening next to the SIM card slot to remove the SIM card.
- ⓘ The Sim Card Slot is located at the top of the rear panel.

Step 2 — Repair SIM card tray



- Cut a piece of tape/ paper approximately the size of your Sim Card and secure it to the back side of the Sim. Be sure to trim any excess.
- ⚠ It's important that you place the tape on the back side of the Sim Card as it will block the communication with the device if placed on the front side
- Slowly slide the Sim Card tray back into the device. It should be a smooth transition, don't force the tray in.
- If the tray is still loose you can keep adding tape/paper until it's no longer loose.

To reassemble your device, follow these instructions in reverse order.