



Parrot AR.Drone Motor Replacement

How to replace a damaged Parrot AR.Drone Motor.

Written By: David Hoyt



INTRODUCTION

How to replace a damaged motor. **Before beginning, check the position of the 4 different propellers, type "A" or "C".**

[video: <http://youtu.be/xVH2djmAAOc>]

Step 1 : Remove the propeller, shaft & gear

Step 2 : Remove the damaged motor screws

Step 3 : Remove the damaged motor

Step 4 : Mount the new motor

Step 5 : Fix the new motor screws

Final step : Fix the propeller, shaft & gear



TOOLS:

- [Parrot AR Drone 2.0 Toolkit](#) (1)

To reassemble your device, follow these instructions in reverse order.