



Nikon Coolpix P90 Battery Replacement

Replace the battery with a fully charged EN-EL5...

Written By: Elizabeth Kamine



INTRODUCTION

Replace the battery with a fully charged EN-EL5 rechargeable Li-ion battery. It provides 3.7V and 1100mAh. Check your battery to ensure you are replacing with a compatible model.

Step 1 — Camera Base



- Use your finger to push the notch of the compartment door to the center of the camera body.
- Release the compartment door, and it will swing open.
- Remove the existing battery with your fingers.

To reassemble your device, follow these instructions in reverse order.