



# iPhone 4 Pentalobe Screws Replacement

5-point Pentalobe screws replacement.

Written By: Walter Galan



---

## INTRODUCTION

This guide shows how to remove the two bottom Pentalobe screws on the iPhone 4.

---



### PARTS:

- [iPhone 4 4S Bottom Screws](#) (1)
-

## Step 1 — Pentalobe Screws



- Use the Pentalobe screwdriver to remove the two 3.6 mm Pentalobe screws near the dock connector.

To reassemble your device, follow these instructions in reverse order.