# Canon PowerShot S410 Battery Replacement

This guide demonstrates how to remove and...

Written By: Randy Lormand



## INTRODUCTION

This guide demonstrates how to remove and replace the battery pack.

### Step 1 — Battery






ⓘ Turn the camera with the bottom side facing up.


- Locate the panel labeled "Batt. Open"
- Place your finger on the panel and slide it in the direction of the arrow.
- The slot will swing open revealing the battery pack.

## Step 2




- Pull the orange lever and the battery will spring out slightly.

## Step 3



- Grasp the battery and fully pull it out of its slot.

When placing the new battery back in the slot, the arrow on the battery must align with the arrow on the camera.

---

After a new battery has been inserted, close the swinging door and you're done.