

iPhone 6s Plus Pentalobe Screws Replacement

Replace or remove the P2 Pentalobe screws in an iPhone 6s Plus.

Written By: Evan Noronha



INTRODUCTION

Follow this guide to replace or remove the P2 Pentalobe screws in your iPhone 6S Plus.



TOOLS:

• P2 Pentalobe Screwdriver iPhone (1)

Step 1 — Pentalobe Screws



- ⚠ Before disassembling your iPhone, discharge the battery below 25%. A charged lithium-ion battery can catch fire and/or explode if accidentally punctured.
- Power off your iPhone before beginning disassembly.
- Remove the two 3.4 mm Pentalobe screws on either side of the Lightning port.

To reassemble your device, follow these instructions in reverse order.