



Koosh Vortex Tornado Barrel Shield Spring Replacement

This guide will show you how to replace the...

Written By: Jordon Roseman



INTRODUCTION

This guide will show you how to replace the barrel shield spring on the Koosh Vortex Tornado.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
- [Spudger](#) (1)

Plastic

Metal Spudger is preferred

Step 1 — Barrel Shield Spring



- Remove the fourteen 15 mm Phillips #1 screws on the side of the body.

Step 2



- Pull the halves of the toy gun apart to show the inside. Set the left half aside (all of the inside components are on the right half).

Step 3



- Using a spudger, unhook the barrel shield's spring from the right half of the toy gun. One side should still be connected to the shield barrel shield.

To reassemble your device, follow these instructions in reverse order.