

MacBook Unibody Model A1278 Battery Replacement

Written By: Andrew Bookholt



INTRODUCTION

Replacing the battery on a MacBook Unibody is an easy task.



PARTS:

MacBook Unibody (Model No. A1278) Battery (1)

Step 1 — Access Door



- With the case closed, place the Unibody top-side down on a flat surface.
- Depress the grooved side of the access door release latch enough to grab the free end. Lift the release latch until it is vertical.

Step 2



 The access door should now be raised enough to lift it up and out of the Unibody.

Step 3 — Battery



- i Be sure the access door release latch is vertical before proceeding.
- Grab the white plastic tab and pull the battery up and out of the Unibody.

To reassemble your device, follow these instructions in reverse order.