



Nikon Coolpix 7900 Battery Replacement

Detail the location of the battery pack, and how to remove it.

Written By: Kaky Payne



Step 1 — Battery



- Press down and forward on cover to open.

Step 2



- Push orange latch forward to release battery.

To reassemble your device, follow these instructions in reverse order.