



Toshiba Satellite L55t-B5271 RAM Replacement

This guide will help you to remove your broken...

Written By: Carson Longendorfer



INTRODUCTION

This guide will help you to remove your broken RAM and replace it with a new one. Since the RAM is frequently updated to ensure top performance, the RAM is very easy to replace.



TOOLS:


[iFixit Opening Tool](#) (1)
[Anti-Static Wrist Strap](#) (1)
[Heavy-Duty Spudger](#) (1)
[Phillips #00 Screwdriver](#) (1)
[Spudger](#) (1)



PARTS:



[Toshiba Satellite L55t-B5271 RAM](#) (1)

Step 1 — Battery



- ① Make sure you turn the laptop off first.
- Close the laptop lid and flip it over so that Toshiba logo is facing down.

Step 2





- Remove the two 6.5 mm Phillips head screws indicated using a Phillips #00 screw driver.

Step 3



- Once the screws are removed, slide the battery pack out of the computer.




Step 4 — Back Panel



- Remove all 6.5 mm Philips head screws on the back cover of the laptop with a Philips #00 screwdriver.
- Use the plastic opening tool to remove the back cover from the laptop.

⚠ Be aware that static discharge can cause damage to sensitive electrical components within the computer. To avoid this you can wear an [anti-static wrist strap](#).

Step 5 — RAM



- ⓘ This laptop does not have a RAM present. Follow instructions to replace your own.
- Evenly press down on the clips on either side of the RAM stick.
 - To pull out the RAM stick, be sure to align the notches on the RAM stick with the notches in the RAM holder.

To reassemble your device, follow these instructions in reverse order.