



Archived

# MacBook Pro 13" Unibody Mid 2009 Trackpad Replacement

This guide has been updated by iFixit staff!...

Written By: SIMRAN



# INTRODUCTION

This guide has been updated by iFixit staff! Read the new, official guide [here](#).



## TOOLS:

Phillips #00 Screwdriver (1)

Spudger (1)

Tri-point Y0 Screwdriver (1)



## PARTS:

MacBook Pro 13" Unibody (Mid 2009-Mid 2012) Trackpad (1)

## Step 1 — Trackpad



- Remove the following 10 screws securing the lower case to the MacBook Pro 13" Unibody:
- Red Seven 3 mm Phillips screws.
- Orange Three 13.5 mm Phillips screws.

## Step 2



- Slightly lift the lower case and push it toward the rear of the computer to free the mounting tabs.


## Step 3



- Remove the following tri-wing screws securing the battery to the upper case:
- Red One 5.5 mm tri-wing screw
- Orange One 13.5 mm tri-wing screw.



## Step 4



- Use the flat end of a spudger to lift the battery connector up out of its socket on the logic board.

## Step 5



- Lift the battery out of the upper case

## Step 6



- Remove the ribbon cable by releasing it from the ZIF connector on the underside of the trackpad and also from the socket that attaches it to the logic board.

## Step 7



- Remove the four 1.2mm #00 Phillips head screws from rear of the trackpad.

To reassemble your device, follow these instructions in reverse order.