

Dyson v6 Absolute Cyclone Replacement

The cyclone of the Dyson v6 Absolute can be easily replaced for regular cleaning and to check for blockages.

Written By: Tabitha Espina Velasco



INTRODUCTION

If there are issues with the suction of the Dyson v6 Absolute, the cyclone may have to be cleaned or replaced.

TOOLS:

- Tweezers (1)
- Heavy-Duty Spudger (1)
- T9 Torx Screwdriver (1)

Step 1 — Bin



• Unplug the device.

Step 2



- Push down the red lever located on the outside of the bin, next to the device handle, to open the door to the debris bin.
- Avoid pressing the trigger on the handle opposite the red lever, which activates the motor.

Step 3



- Push the red lever down a second time to release the debris bin.
- Avoid pressing the trigger on the handle opposite the red lever, which activates the motor.

Step 4



• Pull bin away from the cyclone.

Step 5 — Main Body




• Separate the bin from the main body of the device.

Step 6




 Locate two visible white clips between the main body and the cyclone.

Step 7



- Use tweezers to pinch the white clips together.
- Widely hold the tweezers apart to get them to reach between the two white clips.
- Because the space is tight between the cyclone and the main body, pinching the white clips may require additional effort.

Step 8




- Tilt and pull the main body away from the cyclone.
- There may be a loud snap when the main body separates from the cyclone.

Step 9 — Cyclone




- Use the spudger to remove the cyclone.
- Start at the small opening beneath the place where the cyclone connects to the main body.
- Work the spudger around the rim of the red screen filter.
- You will hear popping noises.

Step 10



• Use a T9 Torx screwdriver to remove five 14mm screws from the edge of the screen filter body.

Step 11



- Remove the filter screen cover away from the cyclone.
- Pull down on the black tube inside the cyclone body to remove it from the cyclone.

To reassemble your device, follow these instructions in reverse order.